











## Ever Knievel Stunt Cycle® 3407-4.

Evel Knlevel roars out of the energizer on his realistically detailed Stunt Cycle and performs exciting wheelies, jumps and flips. The Gyro powered motor sends him racing over 100 feet at top speed Complete with: figure, stunt cycle, G.T. wheelie stand, dare devil flip bar & energizer.

## Evel Kniever Surato Cycle\*\*

Evel Knievel Chopper 3450-4.

Super detailed Chopper does

Comes complete with energizer


all the tricks the Stunt Cycle does.

and figure.

replica of the bike used in the movie "Viva Knievel".

Does all stunts stunt cycle does.

Complete with figure and energizer.



pods "blaze away" as it roars along. Its low profile gives it a classic racing look. It jumps and wheeles like other Evel Knievel vehicles. Complete with figure and energizer.

@ 1877 IDEAL TOY CORP., HOLLIS, N.Y. 11423



KNIEVEL STUNTMEN EVEL

CB.VAN





No. 3412-4

Features: Gull Wing Secret S

MOTORCYC



ers Seat, Operable Drivers Door, nt, Decorative Customizing Labels.









Bull Wing Door, Swivel Drivers Seat, Operable Drivers Door, Secret Storage Compartment, Decorative Customizing Labels.

MOTORCYCLE NOT INCLUDED






























































































2. DIAGRAM 5. The BIKE RACK will hold any Evel Knievel bike. Insert the FRONT FORK of the BIKE into the WELL on the BIKE RACK. Insert the REAR WHEEL into the SLOT.




#### F. JUMP RAMP ASSEMBLY

1. DIAGRAM 6. FOR JUMPS: Fit TWO TABS at END of RAMP into TWO SLOTS at REAR of ROOF. Now you're ready to perform daredevil flips and jumps!



2. DIAGRAM 7. When not in use, carry the JUMP RAMP on the roof. Insert PEGS on ROOF through HOLES in RAMP with RAMP LABEL facing up.




## G. FLIPS AND JUMPS WITH YOUR **EVEL KNIEVEL BIKE**

CAUTION:

As with all toys that go airborne it is advisable that the flight area be clear of other children and other obstacles. In this way chances of accidental injuries, damaged property and a broken toy can be

Place ENERGIZER about 2 feet away from ramp with front edge of Energizer parallel to lower end of ramp as shown.

FLIPS: The Mid-Air Flip is one of the most difficult stunts. Position your Evel Knievel figure on bike with feet in stirrups and arms stretched out to the sides. Bend the figure forward so that its top half leans over the handlebars. Energize bike at a VERY FAST speed. Make sure Energizer is seated firmly on the floor as you turn the handle. When you think the bike is energized enough, STOP winding but HOLD ON TO THE HANDLE so that it does not move. Bike will launch itself up the ramp, over the Van and into a Mid-Air Flip!



### H. JUMPS

Seat Evel Knievel figure on bike with hands on handlebars and feet in stirrups. Energize bike and it'll send Evel Knievel soaring over the Van, and with perfect balance and continue its run!




### ASSEMBLY AND PLAY INSTRUCTIONS

Here's Evel Knievel's California-style van...with moveable doors, bike rack, jump ramp, bench storage area and a super voice unit that talks to you in Evel's own voice. It has lots of room for your E.K. figure & bikes...so get ready good buddy...it's time to get rollin' with the Evel One!


© 1977 IDEAL TOY CORP., HOLLIS, N.Y. 11423

2L-1013




# B. VOICE UNIT ASSEMBLY (requires one AA battery)

- 1. DIAGRAM 2. Turn CB VAN upside down.
- 2. DIAGRAM 2. Hold RIBBON straight out over BATTERY SLOT.
- 3. DIAGRAM 2. Insert one AA BATTERY OVER the RIBBON and INTO the BATTERY SLOT as shown. Make sure the + (plus) and (minus) on the ends of the BATTERY match the + (plus) and (minus) INSIDE the BATTERY SLOT. The RIBBON should now be inside the BATTERY SLOT lying UNDERNEATH the BATTERY.




1. DIAGRAM 3. Push button on top of unit, inside CAB.




# D. TO ADJUST VOICE SPEED

1. DIAGRAM 4. Remove the battery and slide the BUTTON located on the bottom of the BATTERY SLOT. To speed up the voice, slide the button toward the + (plus)... to slow it down, slide the button toward the - (minus) TO REMOVE THE BATTERY: Pull UP on END OF RIBBON. Battery will snap out.



### E. TO ASSEMBLE BIKE RACK

1. Slide the SUPPORTS into the SLOTS on underside of VAN. The SUPPORTS will snap in place just past the REAR AXLE. DO NOT REMOVE THE BIKE RACK ONCE IT IS LOCKED IN PLACE. TO DO SO MAY CAUSE DAMAGE TO THE VEHICLE.





#### THE MONSTER SQUAD \*\* ASSORTMENT 4515-3

Frankenstein, Wolfman, and Dracula characters from the big children's network TV show.

4516-1 "Drac" 4518-7 "Frank" 4517-9 "Bruce"

4 each of 3 styles.

Also available in Open Stock

Pack: 1 doz. Wgt: 4 lbs.

#### MONSTER SQUAD "VAN 4520-3

Replica of the vehicle used on the Monster Squad program. (Figures not included.)

Pack: 6 pcs. Wgt: 26 lbs.

#### KIDS FROM C.A.P.E.R." ASSORTMENT 4505-4

Madcap teen-age detective stars of NBC children's TV series.

4506-2 P.T. 4508-8 Bugs 4507-0 Doc 4509-6 Doomsda

3 each of 4 styles. Also available in Open Stock. Pack: 1 doz. Wgt: 4 lbs.

#### KIDS FROM C.A.P.E.R.'\* BIG BOLOGNA VAN'\* 4510-4

Mobile crime-fighting vehicle, carefully detailed inside and out. (Figures not included.)

Pack: 6 pcs. Wgt: 26 lbs.